




Parts Identification Guide
PIC006/0205

TLM Tube Loader





- TLM**
- 1. Air Cylinder
 - 2. Control
 - 3. Filter
 - 4. Inlet Tube
 - 5. Ratio Valve
 - 6. Sensor